


# Original



CIRCUIT REF. NO.	DESCRIPTION
Q401-402-403	2SC733-Y
Q404-406-408	2SC733-Y
Q405	2SK30-Y
Q407	2SA562-Y

# PLAYBACK AMPLIFIER



1 2 3

TEAC 50939090


4 5

N-0461




CIRCUIT REF. NO.	DESCRIPTION
Q201/Q202-Q205-Q206-Q207	2SC733-Y
Q203/Q204	IC42709

# METER, OUTPUT, OSC ASSY




# MIC, LINE AMPLIFIER




N-0437

CIRCUIT REF. NO.	DESCRIPTION
Q101/Q102-Q103/Q104	IC42709

# MIC, LINE AMPLIFIER




# RECORD AMPLIFIER




CIRCUIT REF. NO.	DESCRIPTION	CIRCUIT REF. NO.	DESCRIPTION	CIRCUIT REF. NO.	DESCRIPTION
Q301-Q303-Q306	25C733-Y	Q302	25C733-Y	Q304	25A562-Y
				Q305	IC 42709

# RECORD AMPLIFIER







# MAIN PC BOARD

